



Wiring Information for the **Slimline-N 12v** Heatmiser Thermostats to work with blower boxes, Webasto/Eberspacher Water Heaters.

For free tech support, please call (01924 274774)

We recommend you use operating mode **00** for blower boxes as it very simple, and **02** if you want a for 7-day timer function for your Webasto or Eberspacher systems.






Operating Mode

The thermostat has 4 main operating modes:

MODE	DESCRIPTION
00	Non-programmable with air sensor only.
01	Non-programmable with floor / air sensor options.
02	Programmable with air sensor only.
03	Programmable with floor / air sensor options (default).


Select the mode that best suits your needs

Mode 00 or 02 MUST NOT be used to control electric underfloor heating, Mode 01 or 03 (default) with floor sensor option must be used.

- Press and hold the Power button to turn the thermostat OFF 
- Press and hold the H key for 10 seconds 
- Use the Up/Down keys to select the mode you require 
- Press A to confirm settings 
- Press the Power button once to turn the thermostat back ON 


Option 1 – Fan Blower 2 speed under < 3 amp

This Heatermister setup is designed to work with a fan blower box under 3 amps of electrical power; this diagram below is for blower boxes with 2 speeds; you have the option to buy a 2 speed switch to work alongside your thermostat, please call for more details.




Option 2 - Fan Blower 1 speed under < 3 amp

Heatermister setup to work with fan blower box under 3 amp of electrical power; this diagram is for blower boxes with 1 speed function.




Option 3 - Fan Blower 2 speed over > 3 amp with relay

Heatermister setup to work with fan blower box over > 3 amp of power with the use of a relay; this diagram is for blower boxes with 2 speeds; you also have the option to buy a 2 speed switch to work alongside your thermostat with a relay kit, please contact us for more details.




Option 4 - Fan Blower 1 speed over > 3 amp with relay

Heatermister setup to work with fan blower box over 3 amp which needs a relay; this diagram is for blower boxes with 1 speed. The relay kit can be purchase direct from us, please contact us for more details,



Option 5 – Webasto Water Heaters



Option 6 – Eberspacher Water Heaters

